

1 Items not included in this box that you will need:


- One AC power cord
- 19" equipment rack
- PSTN cables (RJ 48/coax/fiber)

2 In the box, you will find:


- One TMP6401
- One set of mounting brackets with screws
- One DB-9 to RJ-45 adapter
- SCSI Cables and Patch Panels, if applicable
- Three CAT5 Ethernet Cables (male-male)
- One warranty sheet
- One packing slip
- One TMP6401 Quick Installation Guide



3 Install rack-mounting hardware on TMP6401 and install on equipment rack




4 A) Connect to Tmedia Control Network. B) Connect to VoIP network.




5 Connect to PSTN Network, using one of the following options:

- RJ-48 Interface (T1/E1/J1)
- SCSI Interface (T1/E1/J1), provided with patch panel
- Dual BNC (DS3)
- Optical Interface (OC3/STM-1)



6 A) Connect to power source



B) Verify Power LED = Solid Green (Refer to Panel 3)

7 Connect the TMP6401 serial port to your server. (Refer to panel 3) (Use the DB9 to RJ-45 Adapter.)

8 Using a serial terminal, configure the IP address and gateway. Enter the following command:

- Type `set_boot`

9 Next Steps?

Refer to the Toolpack documentation set for information on configuring and administering your TMP6401.